



NITRITE KIT, LOW RANGE

DROP COUNT, 1 DROP = 50 ppm

CODE 7183-02

QUANTITY	CONTENTS	CODE
15 mL	Ferrioin Indicator	6410-E
2 x 30 mL	*CAN Solution	*2789WT-G
1	Sample Tube, 5-10-25 mL, w/cap	0715

*WARNING: Reagents marked with an * are considered to be potential health hazards. To view or print a Material Safety Data Sheet (MSDS) for these reagents go to www.lamotte.com. To obtain a printed copy, contact LaMotte by e-mail, phone or fax.

PROCEDURE

1. Fill sample tube (0715) to 5 mL line with sample water.
2. Add 8 drops of Ferrioin Indicator (6410). Swirl to mix. Solution will turn orange.
3. While gently swirling tube, add *CAN Solution (2789WT) one drop at a time until color changes from orange to blue. Count number of drops added. Hold bottle vertically.
4. Multiply number of drops used in Step 3 by 50. Record as ppm Sodium Nitrite.

LaMOTTE COMPANY

Helping People Solve Analytical Challenges®

PO Box 329 • Chestertown • Maryland • 21620 • USA
800-344-3100 • 410-778-3100 (Outside U.S.A.) • Fax 410-778-6394

Visit us on the web at www.lamotte.com