

Insta-TEST®
 25 Water Test Strips
Low Range Peroxide
Just DIP & READ!

LaMotte
 Chestertown, MD 21620 USA
 www.lamotte.com




Immerse test strip. Remove with pad face up.
DO NOT SHAKE OFF EXCESS WATER.
 Immediately compare to color chart.

Peroxide	ppm	Code 2984LR
0	1	3
10	30	50

- Keep wet fingers out of the vial.
- For best results, immerse strip to a depth of 12" - 18".
- Close vial tightly after removing strip.
- Store in a cool, dry place.

